
PODMÍNKY UŽITÍ

CZ

Instalace:	Výrobek instalujte pomocí vhodných konzolových systémů. Instalace musí být provedena přesně, aby se zabránilo kývání. Bedna na nářadí není samonosná.
Použití:	Neskladujte v bedně nadměrně těžké materiály / předměty. Zabezpečte, aby se materiály / předměty během jízdy nepohybovaly. Úpravy bedny bez předchozího schválení, nejsou povoleny.
Údržba:	Doporučujeme pravidelné čištění vnějšího prostoru bedny, obzvláště při špatných podmínkách na komunikaci (déšť, bláto, sníh apod.). Čištění provádějte vodou a neutrálním čisticím prostředkem. Použití měkkého textilu (hadrů) je povoleno. Použití abrazivního materiálů se nedoporučuje. V případě poškrábání nebo odření u kovových skříní / beden se doporučuje renovovat lakem pro konkrétní typ materiálu, aby se zabránilo vzniku koroze.

USE AND MAINTENANCE CONDITIONS

EN

Installation:	Install the product using suitable bracketry systems. Installation shall be adequate in order to avoid swinging. The toolbox is not self-supporting.
Use:	Do not store overweight materials (check with the seller the maximum load). Ensure loads and objects then can move during travel. Modifications of the toolbox that have not been notified and authorized are not allowed.
Maintenance:	We recommend a regular frequency cleaning of the outer case and in any case according to the routes and weather and road conditions. Clean with water and a neutral detergent. Use of soft cloth is permitted. Use of abrasive cloth is not recommended. In case of scratches and abrasion of the paint layer it is recommended to renovate the varnish of the toolbox with the same color, in order to avoid the arise of corrosion phenomena.

BAWER**BAWER s.p.a.** | Zona Industriale Jesce 75100 Matera Italy | Tel.: +39 0835 245911 | Fax: +39 0835 245935**ALSAP s.r.o.** | Průmyslová 394 | 267 01 Králův Dvůr u Berouna | E-mail: prodej@alsap.cz | www.alsap.cz